

Setting Up Your Phone

Installing the Battery

Switch off your phone before installing or replacing the battery. The microSDHC™ card is optional and can be installed and removed while the phone is turned on. Unmount the microSDHC card before removing it.

- Place your finger in the slot at the bottom of the back cover to lift and remove the cover.
- Insert the battery by aligning the contacts on the battery with the gold contacts in the battery compartment.
- Gently push down on the battery until it clicks into place.

WARNING! Do not handle a damaged or leaking Li-Ion battery as you can be burned.

Installing the microSDHC Card

You have the option to install a microSDHC card of up to 32 GB to expand your phone's storage capacity.

- Hold your microSDHC card with the metal contacts facing down and slide it into the microSDHC card slot.
- Press the cover gently back into place until you hear a click.

NOTE: Your phone may come with a pre-installed microSDHC card. Some applications may not function normally after you remove the card, pre-installed or otherwise.

Getting to Know Your Phone



Notifications

The status bar at the top of the screen displays phone and service status with various icons on the right side. Below are some of the icons and their meanings.

Checking Phone Status

	GPRS connected		Signal strength
	EDGE connected		No signal
	3G connected		Mobile data in use
	Flight mode		Ringer off
	Battery empty		Vibrate mode
	Battery low		Bluetooth on
	Battery partially drained		Connected to a Wi-Fi network
	Battery full		Wi-Fi in use
	Battery charging		Wired headset connected
	Alarm set		

Copyright © 2013 ZTE CORPORATION. All rights reserved.
No part of this publication may be copied, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation. ZTE Corporation reserves the right to make modifications on print errors or update specifications without prior notice. We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.zteus.com) for more information on self-service and supported product models. Information on the website takes precedence. ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software. Images and screenshots used in this guide may differ from the actual product. Content in this guide may differ from the actual product or software. This guide is published by ZTE Corporation.

ZTE and the ZTE logos are trademarks of ZTE Corporation. Google and Android are trademarks of Google, Inc. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license. microSDHC Logo is a trademark of SD-3C, LLC. Other trademarks and trade names are the property of their respective owners.



QSG Z08170410016

For Your Safety

Radio Frequency (RF) Energy

This model phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States, Industry Canada of Canada.
During SAR testing, this device is set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 0.4 inches (10 mm). Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station (cell tower), the lower the power output.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg, and 1.6 W/kg by Industry Canada.
This device is compliant with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and Canada RSS 102, and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C, and Canada RSS 102. This device has been tested, and meets the FCC, IC RF exposure guidelines when tested with the device directly on the body.
The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: **Q78-Z750C**. For this device, the highest reported SAR value for usage near the head is **1.27 W/kg** for usage near the body is **1.30 W/kg**. While there may be differences between the SAR levels of individual Z750C phones and at various positions, they all meet the government requirement.

SAR compliance for body-worn operation is based on a separation distance of 0.4 inches (10 mm) between the unit and the human body. Carry this device at least 0.4 inches (10 mm) away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 0.4 inches (10 mm) between this device and your body.
RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and using such body-worn accessory should be avoided.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Your Safety (continued)

Radio Frequency Interference

General Statement on Interference

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids. Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Equipment

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff. Consult the airline staff about the use of wireless devices on board the aircraft and enable the airplane mode of your phone when boarding an aircraft.

Interference in Vehicles

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment.

Areas with potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

Touch Screen and Navigation Keys

- Power/Lock Key:** Press and hold to power on, select phone modes, turn on/off airplane mode, or power off. Press to turn on/off the screen display.
- Home Key:** Tap to return to the home screen from any application or screen. Tap and hold to see recently used applications.
- Menu Key:** Tap to get the options for the current screen.
- Back Key:** Tap to go to the previous screen.
- Volume Keys:** Press and hold to turn the volume up or down.

Opening Applications

- Press the **Home Key**. If the current screen is not the home screen.
- Tap **App Drawer**.
- Slide left or right on the screen and tap an app to open it.


Internet

Connecting via Wi-Fi®

- From the home screen, press **Menu** > **System settings** > **Wi-Fi**.
- Slide the **ON/OFF** switch if Wi-Fi is off. Your phone automatically searches for Wi-Fi networks in range and displays their names and security settings. Your phone also connects to previously linked networks when they are in range.
- Tap a network name to connect to it.
- If the network is secured, enter a password or other credentials. (Ask your network administrator for details.)

Connecting via Mobile Network

- From the home screen, press **Menu** > **System settings** > **Mobile networks**.
- Check **Data enabled**.



Using Your Phone With a Hearing Aid Device

Your Z750C is compliant with the FCC Hearing Aid Compatibility (HAC) requirements. For additional HAC information, including the HAC rating of this product, please refer to www.zteusa-support.com. When some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and some also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that have been rated have a label on the box.

Your Z750C has been tested for hearing aid device compatibility and has an M4/T4 rating.

These ratings are not guaranteed. Results will vary, depending on the level of immunity of your hearing device and the degree of your hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate if it meets your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference with hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices contain telecoils.) The more immune your hearing aid device is, the less likely you are to experience interference noise from your wireless phone.

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device.

For additional information about the FCC's actions with regard to hearing aid compatible wireless devices and other steps the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, please go to www.fcc.gov/guid0.

Turning on the HAC Setting

To turn on the HAC function, press **Menu** > **Settings** in the dialer and check **Hearing aids**. For detailed information, refer to "Using Your Phone With a Hearing Aid Device."

This setting applies to T-Rating only and hearing aids that contain telecoils. When the HAC setting is on, your Z750C sends the audio from your phone calls to the telecoil rather than to the microphone of your hearing aid. You are likely to hear calls much better because volume is increased and background noise and feedback are diminished. The HAC setting improves only the calls you listen to through the earpiece. It does not affect calls heard on the speaker or with a headset. HAC requires extra battery power, so watch your battery consumption when it's turned on.

CAUTION: Do not turn on the HAC setting unless you use a hearing aid with a telecoil. Using this setting without a hearing aid or with a hearing aid without a telecoil may be harmful to your hearing.

Distraction Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations when phoning while driving.

Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Calling and Voicemail


Making a Call

- From the home screen, tap **Phone**.
- In the dialer, enter the phone number with the on-screen keypad. Tap **Call** to delete incorrect digits.
- Tap **Phone** to place the call.

NOTE: To call a contact, press **Menu** > **Contacts** and tap **Call**.

Checking Voicemail

- From the home screen, tap **Phone**.
- In the dialer, tap and hold the **1 Key**. If prompted, enter your voicemail password.
- Follow the voice prompts to listen to and manage your voicemail messages.



Customizing Home Screens

You can customize your home screen by adding application shortcuts, folders, widgets, and more.

Adding Shortcuts or Widgets

- From the home screen, tap **App Drawer**.
- If you want to add a widget, tap **Widgets**.
- Tap and hold a widget or an app icon and drag it to the home screen.

Removing Shortcuts or Widgets

- Tap and hold a widget or shortcut on the home screen.
- Drag it to **Remove** to remove it.


Organizing Shortcuts With Folders

- Tap and hold a shortcut on the home screen.
- Drag it to **Folder** at the top of the screen. A new folder is created.
- If needed, drag more shortcuts and drop them into the folder.

Applying New Wallpapers

- From the home screen, press **Menu** > **Wallpaper**.
- Tap **Home** or **Lock screen**.
- Select a wallpaper source from **Gallery**, **Live Wallpapers**, or **Wallpapers** and choose an image.
- Tap **OK** at the top of the screen (for Gallery images) or **SET WALLPAPER**.

NOTE: Swipe left/right to see additional home screens.




Email

Setting Up Gmail™

- From the home screen, tap **App Drawer**.
- NOTE:** If another Gmail account is already set up, press **Menu** > **Settings** > **Add Account**.
- Tap **Existing** to add to your existing Google Account. If you have no Google Accounts, tap **New** to create one.
- Follow the instructions on the screen to set up the account.

Setting Up Email

- From the home screen, tap **App Drawer**.
- NOTE:** If another email account is already set up, press **Menu** > **Settings** > **Add Account**.
- Enter the email address and password.
- Tap **Next** and follow the onscreen instructions.



NOTE: Contact your IT administrator to help set up your corporate Microsoft® Exchange account.

Product Handling

General Statement on Handling and Use

- You alone are responsible for how you use your phone and any consequences of its use. You must always switch off your phone whenever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.
- Always treat your phone and its accessories with care and keep it in a clean and dust-free place.
- Keep the screen and camera lens clean. Unclean screen or camera lens may slow down the phone's reaction to your operations or lower image quality.
- Clean your phone and its accessories with a soft material such as cleaning cloth for eyeglass lenses. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.
- Do not expose your phone or its accessories to open flames or lit tobacco products.
- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories; only authorized personnel must do so.
- Do not expose or use your phone or its accessories in an environment with or that can reach extreme temperatures, minimum 23°F (-5°C) and maximum 122°F (50°C).
- Do not place your phone inside or near heating equipments or high pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your phone may be damaged.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your phone for a long time.

Antenna

Do not touch the antenna unnecessarily.

Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom toward your mouth.

Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area as an airbag inflates with great force and serious injury could result.


Store the phone safely before driving your vehicle.

Seizures/Blackouts

The phone can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video.

If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician.


To reduce the risk of blackouts or seizures, you can use your phone in a well-lit room and take frequent breaks.



Text Messaging

- From the home screen, tap **Messages**.
- Enter the recipient(s) and message text. If you want to send an MMS, add a subject and attachments.
- Tap **Send** to send the message.

Please don't text and drive.



Repetitive Strain Injuries

- To minimize the risk of Repetitive Strain Injury (RSI) when texting or playing games with your phone:
 - Do not grip the phone too tightly.
 - Touch the onscreen keyboard lightly.
 - Use the special features which are designed to minimize the times of touching the onscreen keyboard, such as Message Templates and Predictive Text.
 - Take frequent breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you should not rely solely on any wireless phone for emergency communications.

Loud Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, Bluetooth headsets or other audio devices.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit in the battery terminals. Never puncture the surface of the battery with sharp objects.

Connection to a Car

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessories.

Only qualified personnel can service or repair the phone or its accessories.


If your phone (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Battery Handling & Safety

- Do not disassemble or crush, bend or deform, puncture, or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified by ZTE. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725.
- Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.

Playing Music

- From the home screen, tap **Music**.
- Tap a category, such as Artists or Albums, to find the song you want to play.
- Tap the song to play it. When the song is playing, tap the album artwork to display more options.



Camera and Video


Taking a Photo

- From the home screen, tap **App Drawer**.
- Aim the camera at the subject and make any necessary adjustments.
- Lightly tap **Shutter** or press a **Volume Key**.

Recording a Video

- From the home screen, tap **App Drawer**.
- Switch to the camcorder mode.
- Aim the camera at the subject and make any necessary adjustments.
- Tap **Shutter** to start and **Stop** to stop recording.

TIP: While the recording is in progress, you can tap **Shutter** to save the frame as a photo.



Google Play™

Google Play has tens of thousands of games and applications for you to enjoy. Before you begin, make sure that you have signed in to your Google account.

- From the home screen, tap **App Drawer**.
- Find the app you need either by category or by tapping **Search**.
- Tap the app to see a more detailed description.
- Tap **Install**.
- Read the app permissions and tap **Accept**. CAUTION: Once installed, some apps can access many functions or a significant amount of your personal data. The Play Store will show you what the app can access.
- For paid apps, tap **Continue** and follow additional on-screen instructions for payment.
- Wait for the app to be downloaded and installed automatically. Payment needs to be authorized before paid apps start downloading.
- After the app is successfully installed when the **App** icon appears in the status bar. You can find the new app after pressing **Menu** > **App**.

